



Bipolar Pro Electron Series

Type No.	Case Style	V _{CE} [*] V _{CB0} (V) Min	V _{CE0} (V) Min	V _{EB0} (V) Min	I _{CE} [*] I _{CB0} (nA) Max	V _{CB} (V) Max	h _{FE} h _{FE} @ 1 kHz [*] Min Max	I _C (mA) @ V _{CE} (V) Max	V _{CE(SAT)} (V) Max	V _{BE(SAT)} (V) Min Max	I _C (mA) @ V _{BE(SAT)} (V) Min Max	C _{ob} (pF) Max	f _T (MHz) @ I _C (mA) Min Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BC327	TO-92 (97)	50 [*]	45	5	100 [*]	45	40 100	300 600	0.7	1.2 [*]	500 300						67
BC327A	TO-92 (97)	60 [*]	60	5	100 [*]	45	40 100	300 400	0.7	1.2 [*]	300 500						67
BC327-10	TO-92 (97)	50 [*]	45	5	100 [*]	45	40 63	300 160	0.7	1.2 [*]	500 300						67
BC327-16	TO-92 (97)	50 [*]	45	5	100 [*]	45	40 100	300 250	0.7	1.2 [*]	500 300						67
BC327-25	TO-92 (97)	50 [*]	45	5	100 [*]	45	40 160	300 400	0.7	1.2 [*]	500 300						67
BC328	TO-92 (97)	30 [*]	25	5	100 [*]	25	40 100	300 600	0.7	1.2	500 300						67
BC328-10	TO-92 (97)	30 [*]	25	5	100 [*]	25	40 63	300 160	0.7	1.2	500 300						67
BC328-16	TO-92 (97)	30 [*]	25	5	100 [*]	25	40 100	300 250	0.7	1.2	500 300						67
BC328-25	TO-92 (97)	30 [*]	25	5	100 [*]	25	40 160	300 400	0.7	1.2	500 300						67
BC337	TO-92 (97)	50 [*]	45	5	100	20	100 40	600 500	0.7		500						12
BC337A	TO-92 (97)	60 [*]	60	5	100	20	100 40	400 500	0.7		500						12
BC337-16	TO-92 (97)	50 [*]	45	5	100	20	100 40	250 500	0.7		500						12
BC337-25	TO-92 (97)	50 [*]	45	5	100	20	160 40	400 500	0.7		500						12

T-03-01

Bipolar Pro Electron Series

Bipolar Pro Electron Series

Bipolar Pro Electron Series (Continued)																	
Type No.	Case Style	V _{CE} [*] V _{CB0} (V) Min	V _{CE0} (V) Min	V _{EB0} (V) Min	I _{CB0} [*] (nA) Max	I _{CB0} [*] (nA) Max	h _{FE} h _{FE} 1 kHz [*] Min Max	I _C (mA) @ V _{CE} (V)	V _{CE(SAT)} (V) & V _{BE(ON)} [*] (V) Max Min	V _{BE(SAT)} (V) Max	I _C (mA) @ V _{BE(ON)} [*] (V) Min Max	C _{ob} (pF) Max	f _T (MHz) @ I _C (mA) Min Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BC338	TO-92 (97)	30*	20	5	100	20	100 600 40	100 100 500 1	0.7	0.7	500						12
BC338-16	TO-92 (97)	30*	20	5	100	20	100 250 40	100 100 500 1	0.7	0.7	500						12
BC338-25	TO-92 (97)	30*	20	5	100	20	100 250 40	100 100 500 1	0.7	0.7	500						12
BC368	TO-92 (94)	25*	20	5	10 μA	25	60 85 375 500 60 1A	5 10 500 1 1A 1	0.5	0.5	1A						37
BC369	TO-92 (94)	25*	20	5	10 μA	25	50 85 375 500 60 1A	5 10 500 1 1A 1	0.5	0.5	1A						77
BC546	TO-92 (97)	80	65	6	15	30	110 800 2 5	2 5	0.25	0.25	10			10	(Notes 1, 11)		11
BC546A	TO-92 (97)	80	65	6	15	30	110	0.01 5	0.25	0.25	10			10	(Notes 1, 11)		11
BC546B	TO-92 (97)	80	65	6	15	30	200 450 2 5	0.01 5	0.25	0.6	100			10	(Notes 1, 11)		11
BC547	TO-92 (97)	50	45	6	10	20	125 900 [*] 2 5	2 5	0.25 0.6	0.6	10 100	4.5		10	(Notes 1, 11)		10
BC547A	TO-92 (97)	50	45	6	10	20	125 260 [*] 2 5	2 5	0.25 0.6	0.6	10 100	4.5		10	(Notes 1, 11)		10
BC547B	TO-92 (97)	50	45	6	10	20	240 500 [*] 2 5	2 5	0.25 0.6	0.6	10 100	4.5		10	(Notes 1, 11)		10
BC547C	TO-92 (97)	50	45	5	15	30	420 900 2 5	2 5	0.25 0.6	0.6	10 100	4.5		10	(Notes 1, 11)		10

T-03-01

Bipolar Pro Electron Series (Continued)

Type No.	Case Style	V _{CE(S)} V _{CB0} (V) Min	V _{CEO} (V) Min	V _{EBO} (V) Min	I _{CE(S)} I _{CB0} (mA) Max	h _{FE} h _{FE} @ 1 kHz Min Max	V _{CE(SAT)} (V) & Max	V _{BE(SAT)} V _{BE(ON)} * (V)		I _C (mA) Max	C _{ob} (pF) Max	f _T (MHz) Min Max	I _C (mA) Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
								Min	Max								
BC548	TO-92 (97)	30	20	5	10 20	125 900*	0.25 0.6	0.77* 0.55 0.70*	10 100	4.5					10	(Note 1)	10
BC548A	TO-92 (97)	30	20	5	10 20	125 260*	0.25 0.6	0.77* 0.55 0.70*	10 100	4.5					10	(Note 1)	10
BC548B	TO-92 (97)	30	20	5	10 20	240 500*	0.25 0.6	0.77* 0.55 0.70*	10 100	4.5					10	(Note 1)	10
BC548C	TO-92 (97)	30	20	5	10 20	450 900*	0.25 0.6	0.77* 0.55 0.70*	10 100	4.5					10	(Note 1)	10
BC549	TO-92 (97)	30	20	5	10 20	240 900*	0.25 0.6	0.77* 0.55 0.70*	10 100	4.5					4	(Note 1)	10
BC549B	TO-92 (97)	30	20	5	10 20	240 500*	0.25 0.6	0.77* 0.55 0.70*	10 100	4.5					4	(Note 1)	10
BC549C	TO-92 (97)	30	20	5	10 20	450 900*	0.25 0.6	0.77* 0.55 0.70*	10 100	4.5					4	(Note 1)	10
BC550	TO-92 (97)	50	45	5	10 45	240 900*	0.25 0.6	0.77* 0.55 0.70*	10 100						3	(Note 1)	10
BC550B	TO-92 (97)	50	45	5	10 45	240 500*	0.25 0.6	0.77* 0.55 0.70*	10 100						3	(Note 1)	10
BC556	TO-92 (97)	80	65	5	15 30	75 475 2 5	0.3 0.65	0.77* 0.55 0.70*	10 100						10	(Note 1)	69

Bipolar Pro Electron Series

Bipolar Pro Electron Series

T-03-01

Type No.	Case Style	V _{CE(S)} V _{CB0} (V) Min	V _{CE0} (V) Min	V _{EB0} (V) Min	I _{CS} [*] I _{CB0} (nA) Max	h _{FE} h _{FE} @ 1 kHz Min Max	I _C (mA) V _{CE} (V)	V _{CE(SAT)} (V) & V _{BE(ON)} [*] (V) Max Min	I _C (mA) V _{BE(SAT)} (V) Max Min	C _{ob} (pF) Max	f _T (MHz) Min Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BC556A	TO-92 (97)	80	65	5	15 30	125 250	2 5	0.3 0.65	10 100				10	(Note 1)	69
BC556B	TO-92 (97)	80	65	5	15 30	220 475	2 5	0.3 0.65	10 100				10	(Note 1)	69
BC557	TO-92 (97)	50	45	5	100 20	75 900*	2 5	0.3 0.65	10 100				10	(Note 1)	68
BC557A	TO-92 (97)	50	45	5	100 20	125 260*	2 5	0.3 0.65	10 100				10	(Note 1)	68
BC557B	TO-92 (97)	50	45	5	100 20	240 500*	2 5	0.3 0.65	10 100				10	(Note 1)	68
BC558	TO-92 (97)	30	25	5	100 20	75 500*	2 5	0.3 0.65	10 100				10	(Note 1)	68
BC558A	TO-92 (97)	30	25	5	100 20	125 260*	2 5	0.3 0.65	10 100				10	(Note 1)	68
BC558B	TO-92 (97)	30	25	5	100 20	240 500*	2 5	0.3 0.65	10 100				10	(Note 1)	68
BC558C	TO-92 (97)	30	25	5	100 20	450 900*	2 5	0.3 0.65	10 100				10	(Note 1)	68
BC559	TO-92 (97)	25	20	5	100 20	125 500*	2 5	0.3 0.65	10 100				4	(Note 1)	68

Bipolar Pro Electron Series (Continued)

Bipolar Pro Electron Series

Type No.	Case Style	V _{CE} [*] V _{CB0} (V) Min	V _{CE0} (V) Min	V _{EB0} (V) Min	I _{CE0} [*] I _{CB0} (mA) Max	H _{FE} h _{FE} @ 1 kHz Min Max	I _C (mA) V _{CE} (V)	V _{CE(SAT)} (V) & V _{BE(ON)} [*] (V) Max Min	I _C (mA) V _{CE(SAT)} (V) & V _{BE(ON)} [*] (V) Max Min	C _{ob} (pF) Max	f _T (MHz) Min Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BC559B	TO-92 (97)	25	20	5	100 20	240 500*	2 5	0.3 0.65 0.82* 0.75*	10 100 2				4	(Note 1)	68
BC559C	TO-92 (97)	25	20	5	100 20	450 900*	2 5	0.3 0.65 0.82* 0.75*	10 100 2				4	(Note 1)	68
BC560	TO-92 (97)	50	45	5	100 45	125 500*	2 5	0.3 0.65 0.82* 0.75*	10 100 2				3	(Note 1)	68
BC560B	TO-92 (97)	50	45	5	100 45	240 500*	2 5	0.3 0.65 0.82* 0.75*	10 100 2				3	(Note 1)	68
BC635	TO-92 (94)	45	45	5		25 40 250 25	5 2 150 2 500 2	0.5	500						38
BC636	TO-92 (94)	45	45	5	100 30	25 40 250 25	5 2 150 2 500 2	0.5	500						78
BC637	TO-92 (94)	60	60	5		25 40 250 25	5 2 150 2 500 2	0.5	500						38*
BC638	TO-92 (94)	60	60	5	100 30	25 40 250 25	5 2 150 2 500 2	0.5	500						78
BC639	TO-92 (94)	100	80	5		25 40 250 25	5 2 150 2 500 2	0.5	500						39
BC640	TO-92 (94)	100	80	5	100 30	25 40 250 25	5 2 150 2 500 2	0.5	500						79
BC807	TO-236 (49)	50*	45	5	100 20	100 600 40	100 1 500 1	0.7	500						67

T-03-01

Bipolar Pro Electron Series

Bipolar Pro Electron Series (Continued)															
Type No.	Case Style	V _{CE} * V _{CB0} (V) Min	V _{CE0} (V) Min	V _{EB0} (V) Min	I _{CE} * I _{CB0} (nA) Max	H _{FE} h _{FE} @ 1 kHz* Min Max	I _C (mA) V _{CE} (V) 1	V _{CE(SAT)} (V) & V _{BE(ON)*} (V) Max Min	I _C (mA) Min Max	C _{ob} (pF) Max	f _T (MHz) Min Max	f _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BC807-16	TO-236 (49)	50*	45	5	100 20	100 250 40	100 1 500 1	0.7	500						67
BC807-25	TO-236 (49)	50*	45	5	100 20	160 400 40	100 1 500 1	0.7	500						67
BC807-40	TO-236 (49)	50*	45	5	100 20	250 600 40	100 1 500 1	0.7	500						67
BC808	TO-236 (49)	30*	25	5	100 20	100 600 40	100 1 500 1	0.7	500						67
BC808-16	TO-236 (49)	30*	25	5	100 20	100 250 40	100 1 500 1	0.7	500						67
BC808-25	TO-236 (49)	30*	25	5	100 20	160 400 40	100 1 500 1	0.7	500						67
BC808-40	TO-236 (49)	30*	25	5	100 20	250 600 40	100 1 500 1	0.7	500						67
BC817	TO-236 (49)	30*	25	5	100 20	100 600 40	100 1 500 1	0.7	500						12
BC817-16	TO-236 (49)	30*	25	5	100 20	100 250 40	100 1 500 1	0.7	500						12
BC817-25	TO-236 (49)	30*	25	5	100 20	160 400 40	100 1 500 1	0.7	500						12
BC817-40	TO-236 (49)	30*	25	5	100 20	250 600 40	100 1 500 1	0.7	500						12
BC818	TO-236 (49)	30*	25	5	100 20	100 600 40	100 1 500 1	0.7	500						12
BC818-16	TO-236 (49)	30*	25	5	100 20	100 250 40	100 1 500 1	0.7	500						12
BC818-25	TO-236 (49)	30*	25	5	100 20	160 400 40	100 1 500 1	0.7	500						12

T-03-01

Bipolar Pro Electron Series (Continued)

Type No.	Case Style	V _{CE} [*] V _{CB0} (V) Min	V _{CE0} (V) Min	V _{EB0} (V) Min	I _{CB0} [*] I _{CB0} (nA) Max	V _{CB} (V) Max	h _{FE} h _{FE} @ 1 kHz Min Max	I _C (mA) Min Max	V _{CE(SAT)} V _{CE(SAT)} (V) & V _{BE(ON)} [*] V _{BE(ON)} (V) Min Max	V _{BE(SAT)} V _{BE(SAT)} (V) Min Max	I _C (mA) Min Max	C _{ob} (pF) Max	f _T (MHz) Min Max	I _C (mA) Min Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BC818-40	TO-236 (49)	30*	25	5	100	20	250 600 40 1	100 1 500 1	0.7		500							12
BC846	TO-236 (49)	80	65	6	15	30	110	0.01 5 800 2 5	0.25	0.25	10					10	(Note 1)	11
BC846-A	TO-236 (49)	80	65	6	15	30	110	0.01 5 220 2 5	0.25	0.25	10					10	(Note 1)	11
BC846-B	TO-236 (49)	80	65	6	15	30	200	0.01 5 450 2 5	0.25	0.25	10					10	(Note 1)	11
BC847	TO-236 (49)	50	45	6	15	30	110	0.01 5 800 2 5	0.25	0.25	10					10	(Note 1)	10
BC847-A	TO-236 (49)	50	45	6	15	30	110	0.01 5 220 2 5	0.25	0.25	10					10	(Note 1)	10
BC847-B	TO-236 (49)	50	45	6	15	30	200	0.01 5 450 2 5	0.25	0.25	10					10	(Note 1)	10
BC848	TO-236 (49)	30	30	5	15	30	110	0.01 5 800 2 5	0.25	0.25	10					10	(Note 1)	10
BC848-A	TO-236 (49)	30	30	5	15	30	110	0.01 5 220 2 5	0.25	0.25	10					10	(Note 1)	10
BC848-B	TO-236 (49)	30	30	5	15	30	200	0.01 5 450 2 5	0.25	0.25	10					10	(Note 1)	10
BC848-C	TO-236 (49)	30	30	5	15	30	420	0.01 5 800 2 5	0.25	0.25	10					10	(Note 1)	10

Bipolar Pro Electron Series

7

Bipolar Pro Electron Series

Type No.	Case Style	V _{CE} *		V _{CE0} (V) Min	V _{EBO} (V) Min	I _{CB0} (mA) Max	I _{CB0} (mA) Max	HFE h _{FE} @ 1 kHz	I _C (mA)	V _{CE} (V) Max	V _{BE(SAT)} (V) Max	V _{BE(ON)} (V) Min	I _C (mA) Max	C _{ob} (pF) Max	f _T (MHz) Min	I _C (mA) Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
		V _{CB0} (V) Min	V _{CB} (V) Max																	
BC849	TO-236 (49)	30	30	30	5	15	30	200	0.01	5	0.25		10					4	(Note 1)	10
BC849B	TO-236 (49)	30	30	30	5	15	30	200	0.01	5	0.25		10					4	(Note 1)	10
BC849C	TO-236 (49)	30	30	30	5	15	30	420	0.01	5	0.25		10					4	(Note 1)	10
BC850	TO-236 (49)	50	45	45	5	15	30	200	0.01	5	0.25		10					3	(Note 1)	10
BC850-B	TO-236 (49)	50	45	45	5	15	30	200	0.01	5	0.25		10						(Note 1)	10
BC856	TO-236 (49)	80	65	65	5	15	30	75	2	5	0.3		10					10	(Note 1)	69
BC856-A	TO-236 (49)	80	65	65	5	15	30	125	2	5	0.65		100					10	(Note 1)	69
BC856-B	TO-236 (49)	80	65	65	5	15	30	220	2	5	0.3		10					10	(Note 1)	69
BC857	TO-236 (49)	50	45	45	5	15	30	75	2	5	0.3		10					10	(Note 1)	68
BC857-A	TO-236 (49)	50	45	45	5	15	30	125	2	5	0.65		100					10	(Note 1)	68

T-03-01

Bipolar Pro Electron Series (Continued)

Type No.	Case Style	V _{CE0} [*] V _{CB0} (V) Min	V _{EB0} (V) Min	V _{CE0} [*] I _{CB0} @ (nA) (V) Max	H _{FE} h _{FE} 1 kHz [*] Min Max	V _{CE} (V) Min	I _C (mA) Min Max	V _{CE(SAT)} (V) & V _{BE(ON)} (V) Max Min	V _{BE(SAT)} V _{BE(ON)} (V) Min Max	I _C (mA) Min Max	C _{ob} (pF) Max	f _T (MHz) @ I _C (mA) Min Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BC857-B	TO-236 (49)	50	45	5	15	30	220 475 2 5	0.3	10	10				10	(Note 1)	68
BC858	TO-236 (49)	30	30	5	15	30	75 800 2 5	0.3	10	100				10	(Note 1)	68
BC858-B	TO-236 (49)	30	30	5	15	30	220 475 2 5	0.3	10	100				10	(Note 1)	68
BC858-C	TO-236 (49)	30	30	5	15	30	420 800 2 5	0.3	10	100				10	(Note 1)	68
BC859	TO-236 (49)	30	30	5	15	30	220 800 2 5	0.65	100	100				4	(Note 1)	68
BC859-A	TO-236 (49)	30	30	5	15	30	125 250 2 5	0.65	100	100				4	(Note 1)	68
BC859-B	TO-236 (49)	30	30	5	15	30	220 475 2 5	0.65	100	100				4	(Note 1)	68
BC859-C	TO-236 (49)	30	30	5	15	30	420 800 2 5	0.65	100	100				4	(Note 1)	68
BC860	TO-236 (49)	50	45	5	15	30	220 800 2 5	0.3	10	100				3	(Note 1)	68
BC860-B	TO-236 (49)	50	45	5	15	30	220 475 2 5	0.3	10	100				3	(Note 1)	68
BCF29	TO-236 (49)	32	32	5	100	32	120 0.01 5 5	0.3	10	10				4	(Note 1)	68
BCF30	TO-236 (49)	32	32	5	100	32	200 0.01 5 5	0.25	10	10				4	(Note 1)	68
BCF32	TO-236 (49)	50	45	5	100	20	215 0.01 5 5	0.3	10	10				4	(Note 1)	10

T-03-01

Bipolar Pro Electron Series

7

Bipolar Pro Electron Series

Bipolar Pro Electron Series (Continued)																		
Type No.	Case Style	V _{CE} [*] V _{CB0} (V) Min	V _{CE0} (V) Min	V _{EB0} (V) Min	I _{CE} [*] I _{CB0} (mA) Max	V _{CB} (V)	H _{FE} h _{FE} @ 1 kHz Min Max	I _C (mA) Min Max	V _{CE} (V) Min Max	V _{CE(SAT)} (V) & V _{BE(ON)} (V) Max	V _{BE(SAT)} (V) Min Max	I _C (mA) Min Max	C _{ob} (pF) Max	f _T (MHz) Min Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BCF33	TO-236 (49)	50	45	5	100	20	200	0.01 5 450 2 5	5	0.3		10				4	(Note 1)	10
BCF70	TO-236 (49)	50	45	5	100	20	215	0.01 5 500 2 5	5	0.3		10				4	(Note 1)	10
BCV26	TO-236 (49)	40	30	10	100	30	4,000 10,000 20,000	1 5 10 5 100 5	5	1.0	1.5	100						61
BCV27	TO-236 (49)	40	30	10	100	30	4,000 10,000 20,000	1 5 10 5 100 5	5	1.0	1.5	100						05
BCV71	TO-236 (49)	80	60	5	100	20	110	220 2 5	5	0.25		10				10	(Note 1)	11
BCV72	TO-236 (49)	80	60	5	100	20	200	450 2 5	5	0.25		10				10	(Note 1)	11
BCW29	TO-236 (49)	32	32	5	100	32	120	0.01 5 260 2 5	5	0.3		10				10	(Note 1)	68
BCW30	TO-236 (49)	32	32	5	100	32	215	0.01 5 500 2 5	5	0.3		10				10	(Note 1)	68
BCW31	TO-236 (49)	32	32	5	100	32	150	0.01 5 270 2	5	0.25		10				10	(Note 1)	10
BCW32	TO-236 (49)	32	32	5	100	32	200	0.01 5 420 2	5	0.25		10				10	(Note 1)	10
BCW33	TO-236 (49)	32	32	5	100	32	450	0.01 5 800 2	5	0.25		10				10	(Note 1)	10
BCW60	TO-236 (49)	32*	32	5	20	32	50 120	50 1 630 2 5	1	0.35	0.6 0.85	50				6	(Note 1)	10
BCW61	TO-236 (49)	32*	32	5	20	32	50 120	50 1 630 2 5	1	0.25	0.6 0.85	50				6	(Note 1)	68
BCW65	TO-236 (49)	60	32	5	20*	32	35 75 100	0.1 10 220 10 1 250 100 1 500 500 1	10		2.0	500	12	100		10	(Note 1)	10

T-03-01

Bipolar Pro Electron Series (Continued)

Type No.	Case Style	V _{CE0} [*] (V) Min	V _{CE0} [*] (V) Max	V _{BE0} [*] (V) Min	V _{BE0} [*] (V) Max	I _{CB0} [*] (mA) Max	I _{CB0} [*] (mA) Min	V _{CB} (V)	h _{FE} 1 kHz [*] Min	h _{FE} 1 kHz [*] Max	I _C (mA) Min	I _C (mA) Max	V _{CE(SAT)} (V) Max	V _{BE(SAT)} (V) Min	V _{BE(ON)} [*] (V) Max	I _C (mA) Max	C _{ob} (pF) Max	f _T (MHz) Min	f _T (MHz) Max	I _C (mA) Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BCW66	TO-236 (49)	45	5	45	20*	45	35	0.1	10	10	0.1	10	0.3	2.0	500	12	100	20			10	(Note 1)	10	
BCW68	TO-236 (49)	45	5	45	20*	45	35	0.1	10	10	0.1	10	0.3	2.0	500	12	100	20			10	(Note 1)	10	
BCW69	TO-236 (49)	45	5	45	100	20	120	260	2	5	0.3	10	0.3									(Note 1)	68	
BCW70	TO-236 (49)	45	5	45	100	20	215	500	2	5	0.3	10	0.3									(Note 1)	68	
BCW71	TO-236 (49)	45	5	45	100	20	110	220	2	5	0.25	10	0.25										68	
BCW72	TO-236 (49)	45	5	45	100	20	200	450	2	5	0.25	10	0.25									(Note 1)	68	
BCW81	TO-236 (49)	45	5	45	100	20	420	800	2	5	0.25	10	0.25									(Note 1)	10	
BCW89	TO-236 (49)	60	5	60	100	20	120	260	2	5	0.3	10	0.3									(Note 1)	68	
BCX17	TO-236 (49)	45	5	45	100	20	100	600	100	1	0.62	500	0.62											67
BCX18	TO-236 (49)	25	5	25	100	20	100	600	100	1	0.62	500	0.62											67
BCX19	TO-236 (49)	45	5	45	100	20	100	600	100	1	0.62	500	0.62	1.2	500									12
BCX20	TO-236 (49)	25	5	25	100	20	100	600	100	1	0.62	500	0.62	1.2	500									12

T-03-01

Bipolar Pro Electron Series

7

Bipolar Pro Electron Series

Type No.	Case Style	V _{CE0} [*] (V) Min	V _{CE0} [*] (V) Min	V _{EB0} (V) Min	I _{CB0} [*] (mA) Max	h _{FE} h _{FE} 1 kHz [*] Min Max	I _C (mA) @ Min Max	V _{CE(SAT)} (V) Max	V _{BE(SAT)} (V) Min Max	C _{ob} (pF) Max	f _T (MHz) Min Max	I _C (mA) @ Min Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BCX58	TO-92 (97)		32	7	10	120 80 40	2 10 100	5			125	10	800	6	(Notes 3 & 4)	10
BCX58-7	TO-92 (97)		32	7	10	120 80 40	2 10 100	5			125	10	800	6	(Notes 3 & 4)	10
BCX58-8	TO-92 (97)		32	7	10	20 180 120 45	0.01 2 10 100	5			125	10	800	6	(Notes 3 & 4)	10 10
BCX58-9	TO-92 (97)		32	7	10	40 250 160 60	0.01 2 10 100	5			125	10	800	6	(Notes 3 & 4)	10
BCX58-10	TO-92 (97)		32	7	10	100 380 240 60	0.01 2 10 100	5			125	10	800	6	(Notes 3 & 4)	10
BCX59	TO-92 (97)		45	7		120 80 40	2 10 100	5	0.5		125	10	800		(Note 5)	10
BCX59-7	TO-92 (97)		45	7		120 80 40	2 10 100	5	0.5		125	10	800		(Note 5)	10
BCX59-8	TO-92 (97)		45	7		20 180 120 45	0.01 2 10 100	5	0.5		125	10	800		(Note 5)	10

T-03-01

Bipolar Pro Electron Series (Continued)

Type No.	Case Style	V _{CE0} [*] (V) Min	V _{CB0} [*] (V) Min	V _{CE0} [*] (V) Min	V _{EBO} (V) Min	I _{CB0} [*] (mA) Max	I _{CE0} [*] (mA) Max	h _{FE}		I _C (mA) Max	V _{CE(SAT)} (V) Max	V _{BE(SAT)} (V) Min Max		I _C (mA) Max	C _{ob} (pF) Max	f _T (MHz) Min Max	I _C (mA) Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
								Min	Max			Min	Max								
BCX59-9	TO-92 (97)	45		45	7		0.01	40 250 160 60	220 460 630 100	2	0.5	1.0	100		125	10	800			(Note 5)	10
BCX59-10	TO-92 (97)	45		45	7		0.01	100 380 240 60	220 630 1000 100	2	0.5	1.0	100		125	10	800			(Note 5)	10
BCX70G	TO-236 (49)	45	45	45	5	20	2	120 60	220 50	2	0.55	0.7	50	4.5	125	10	800		6	(Notes 17, 19)	10
BCX70H	TO-236 (49)	45	45	45	5	20	2	180 70 20	310 50 0.01	2	0.55	0.7	50	4.5	125	10	800		6	(Notes 17, 19)	10
BCX70J	TO-236 (49)	45	45	45	5	20	2	250 90 40	460 50 0.01	2	0.55	0.7	50	4.5	125	10	800		6	(Notes 17, 19)	10
BCX71G	TO-236 (49)	45	45	45	5	20	2	120 60	220 50	2	0.55	0.7	50	4.5	125	10	800		6	(Notes 17, 19)	68
BCX71H	TO-236 (49)	45	45	45	5	20	2	180 70 20	310 50 0.01	2	0.55	0.7	50	4.5	125	10	800		6	(Notes 17, 19)	68
BCX71J	TO-236 (49)	45	45	45	5	20	2	250 90 40	460 50 0.01	2	0.55	0.7	50	4.5	125	10	800		6	(Notes 17, 19)	68
BCX78	TO-92 (97)	32		32	5		2	120 80 40	630 1000 100	2	0.6	1.0	100	4.5	200	10			6	(Note 1)	68
BCX78-7	TO-92 (97)	32		32	5		2	120 80 40	220 10 100	2	0.6	1.0	100	4.5	200	10			6	(Note 1)	68

T-03-01

Bipolar Pro Electron Series

Bipolar Pro Electron Series

Type No.	Case Style	V _{CE0} (V)		V _{CE0} (V) Min	V _{BE0} (V) Min	I _{CE0} (mA) Max	I _{CB0} (mA) Max	H _{FE} I _{re} @ 1 kHz* Min Max	I _C (mA) V _{CE} (V) Min Max	V _{CE(SAT)} (V) & V _{BE(SAT)} (V) Min Max	I _C (mA) V _{BE(SAT)} (V) Min Max	C _{ob} (pF) Max	f _T (MHz) Min Max	I _C (mA) @ Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
		Min	Max															
BCX78-8	TO-92 (97)	32	5	30	0.01 5	180 310 2 5	120 400 10 1	45	0.6	1.0	100	4.5	200	10		6	(Note 1)	68
BCX78-9	TO-92 (97)	32	5	40	0.01 5	250 460 2 5	160 630 10 1	60	0.6	1.0	100	4.5	200	10		6	(Note 1)	68
BCX78-10	TO-92 (97)	32	5	100	0.01 5	380 630 2 5	240 1000 10 1	60	0.6	1.0	100	4.5	200	10		6	(Note 1)	68
BCX79	TO-92 (97)	45	5	80	10 1	40 100 1	120 630 2 5	80	0.6	1.0	100	4.5	200	10		6	(Note 1)	68
BCX79-7	TO-92 (97)	45	5	120	2 5	120 220 2 5		120	0.6	1.0	100	4.5	200	10		6	(Note 1)	68
BCX79-8	TO-92 (97)	45	5	120	10 1	45 100 1		120	0.6	1.0	100	4.5	200	10		6	(Note 1)	68
BCX79-9	TO-92 (97)	45	5	160	10 1	60 100 1		160	0.6	1.0	100	4.5	200	10		6	(Note 1)	68
BCX79-10	TO-92 (97)	45	5	240	10 1	60 100 1		240	0.6	1.0	100	4.5	200	10		6	(Note 1)	68
BD370A	TO-237 (91)	80	45	25	500 2	40 400 100 1		100	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	78

T-03-01

Bipolar Pro Electron Series (Continued)

Type No.	Case Style	V _{CE0} [*] V _{CB0} (V) Min	V _{CE0} [*] V _{CB0} (V) Min	V _{EB0} (V) Min	I _{CB0} [*] I _{CB0} (mA) Max	I _{CB0} [*] I _{CB0} (mA) Max	HFE h _{FE} @ 1 kHz [*] Min Max	I _C (mA) Min Max	V _{CE} (V) 1 2	V _{CE(SAT)} (V) & V _{BE(ON)} (V) Max	V _{BE(SAT)} V _{BE(ON)} (V) Min Max	I _C (mA) Min Max	C _{ob} (pF) Max	f _T (MHz) Min Max	I _C (mA) Min Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BD370A-10	TO-237 (91)	80	45		100	45	25 63	500 100	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	78
BD370A-16	TO-237 (91)	80	45		100	45	25 100	500 250	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	78
BD370A-25	TO-237 (91)	80	45		100	45	25 160	500 400	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	78
BD370B	TO-237 (91)	80	60		100	60	25 40	500 400	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	78
BD370B-10	TO-237 (91)	80	60		100	60	25 63	500 160	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	78
BD370B-16	TO-237 (91)	80	60		100	60	25 100	500 250	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	78
BD370B-25	TO-237 (91)	80	60		100	60	25 160	500 400	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	78
BD370C	TO-237 (91)	80	80		100	80	25 40	500 400	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	78
BD370C-6	TO-237 (91)	80	80		100	80	25 40	500 100	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	78
BD370C-10	TO-237 (91)	80	80		100	80	25 63	500 160	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	78
BD370C-16	TO-237 (91)	80	80		100	80	25 100	500 250	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	78
BD370D	TO-237 (91)	80	100		100	80	25 40	500 400	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	38
BD370D-6	TO-237 (91)	80	100		100	80	25 40	500 100	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	38
BD370D-10	TO-237 (91)	80	100		100	80	25 63	500 160	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	38
BD371A	TO-237 (91)	80	45		100	45	25 40	500 400	2 1	0.7	1.2*	1A	30	50	200	420	6	(Notes 5 & 6)	38

T-03-01

Bipolar Pro Electron Series

7

Bipolar Pro Electron Series

Type No.	Case Style	V _{CE} * V _{CB0} (V) Min	V _{CE0} (V) Min	V _{EB0} (V) Min	I _{CB0} * I _{CB0} (mA) Max	HFE h _{FE} @ 1 kHz* Min Max	I _C I _C (mA) Min Max	V _{CE(SAT)} V _{CE(SAT)} (V) & V _{BE(ON)} (V) Min Max	V _{BE(SAT)} V _{BE(SAT)} (V) Min Max	C _{ob} (pF) Max	f _T (MHz) Min Max	I _C (mA) Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BD371A-10	TO-237 (91)	80	45		100 45	25 500 2 63 160 100 1	500 2 100 1	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	38
BD371A-16	TO-237 (91)	80	45		100 45	25 500 2 100 250 100 1	500 2 100 1	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	38
BD371A-25	TO-237 (91)	80	45		100 45	25 500 2 180 400 100 1	500 2 100 1	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	38
BD371B	TO-237 (91)	80	60		100 60	25 500 2 40 400 100 1	500 2 100 1	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	38
BD371B-10	TO-237 (91)	80	60		100 60	25 500 2 63 160 100 1	500 2 100 1	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	38
BD371B-16	TO-237 (91)	80	60		100 60	25 500 2 100 250 100 1	500 2 100 1	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	38
BD371B-25	TO-237 (91)	80	60		100 60	25 500 2 160 400 100	500 2 100	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	38
BD371C	TO-237 (91)	80	80		100 80	25 500 2 40 400 100 1	500 2 100 1	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	38
BD371C-6	TO-237 (91)	80	80		100 80	25 500 2 40 100 100 1	500 2 100 1	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	38
BD371C-10	TO-237 (91)	80	80		100 80	25 500 2 63 160 100 1	500 2 100 1	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	38
BD371C-16	TO-237 (91)	80	80		100 80	25 500 2 100 250 100 1	500 2 100 1	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	38
BD371D	TO-237 (91)	80	100		100 100	25 500 2 40 400 100 1	500 2 100 1	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	39
BD371D-6	TO-237 (91)	80	100		100 100	25 500 2 40 100 100 1	500 2 100 1	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	39
BD371D-10	TO-237 (91)	80	100		100 100	25 500 2 63 160 100 1	500 2 100 1	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	39
BD372A	TO-237 (90)	80	45		100 45	25 500 2 40 400 100 1	500 2 100 1	0.7 1.2* 1A	1.2* 1A	30	50	200	420	6	(Notes 5 & 6)	78

T-03-01

Bipolar Pro Electron Series (Continued)

Type No.	Case Style	V _{CE0} [*] (V) Min	V _{CE0} [*] (V) Max	V _{BE0} [*] (V) Min	V _{BE0} [*] (V) Max	I _{CB0} [*] (mA) Max	I _{CB0} [*] (mA) Min	V _{CB} [*] (V) Max	HFE I _{hfe} 1 kHz Min Max	I _C (mA) Max	V _{CE} (V) Max	V _{CE(SAT)} (V) Max	V _{BE(SAT)} (V) Max	V _{BE(ON)} (V) Min Max	I _C (mA) Max	C _{ob} (pF) Max	f _T (MHz) Min Max	I _C (mA) Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BD372A-10	TO-237 (90)	80	45			100	45	25	63	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	78
BD372A-16	TO-237 (90)	80	45			100	45	25	100	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	78
BD372A-25	TO-237 (90)	80	45			100	45	25	160	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	78
BD372B	TO-237 (90)	80	60			100	60	25	40	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	78
BD372B-10	TO-237 (90)	80	60			100	60	25	63	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	78
BD372B-16	TO-237 (90)	80	60			100	60	25	100	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	78
BD372B-25	TO-237 (90)	80	60			100	60	25	160	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	78
BD372C	TO-237 (90)	80	80			100	80	25	40	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	78
BD372C-6	TO-237 (90)	80	80			100	80	25	40	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	78
BD372C-10	TO-237 (90)	80	80			100	80	25	63	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	78
BD372C-16	TO-237 (90)	80	100			100	100	25	100	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	78
BD372D	TO-237 (90)	80	100			100	100	25	40	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	79
BD372D-6	TO-237 (90)	80	100			100	100	25	40	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	79
BD372D-10	TO-237 (90)	80	100			100	100	25	63	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	79
BD373A	TO-237 (90)	80	45			100	45	25	40	500	2	0.7	1.2*	1A	30	30	50	200	420	6	(Notes 5 & 6)	38

T-03-01

Bipolar Pro Electron Series

7

Bipolar Pro Electron Series

Bipolar Pro Electron Series (Continued)																
Type No.	Case Style	V _{CE} [*] V _{CB0} (V) Min	V _{CE0} (V) Min	V _{EB0} (V) Min	I _{CB0} [*] (nA) Max	H _{FE} h _{FE} @ 1 kHz [*] Min Max	I _C (mA) Max	V _{CE} ^(SAT) (V) & Max	V _{BE(SAT) V_{BE(ON)}[*] (V) Min Max}	I _C (mA) Max	C _{ob} (pF) Max	f _T (MHz) Min Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BD373A-10	TO-237 (90)	80	45		100	25 63	500 100	0.7	1.2*	1A	30	50	420	6	(Notes 5 & 6)	38
BD373A-16	TO-237 (90)	80	45		100	25 100	500 250	0.7	1.2*	1A	30	50	420	6	(Notes 5 & 6)	38
BD373A-25	TO-237 (90)	80	45		100	25 160	500 400	0.7	1.2*	1A	30	50	420	6	(Notes 5 & 6)	38
BD373B	TO-237 (90)	80	80		100	25 40	500 100	0.7	1.2*	1A	30	50	420	6	(Notes 5 & 6)	38
BD373B-10	TO-237 (90)	80	60		100	25 63	500 100	0.7	1.2*	1A	30	50	420	6	(Notes 5 & 6)	38
BD373B-16	TO-237 (90)	80	60		100	25 100	500 250	0.7	1.2*	1A	30	50	420	6	(Notes 5 & 6)	38
BD373B-25	TO-237 (90)	80	60		100	25 160	500 400	0.7	1.2*	1A	30	50	420	6	(Notes 5 & 6)	38
BD373C	TO-237 (90)	80	80		100	25 40	500 100	0.7	1.2*	1A	30	50	420	6	(Notes 5 & 6)	38
BD373C-6	TO-237 (90)	80	80		100	25 40	500 100	0.7	1.2*	1A	30	50	420	6	(Notes 5 & 6)	38
BD373C-10	TO-237 (90)	80	80		100	25 63	500 100	0.7	1.2*	1A	30	50	420	6	(Notes 5 & 6)	38
BD373C-16	TO-237 (90)	80	80		100	25 100	500 250	0.7	1.2*	1A	30	50	420	6	(Notes 5 & 6)	38
BD373D	TO-237 (90)	80	100		100	25 40	500 400	0.7	1.2*	1A	30	50	420	6	(Notes 5 & 6)	38
BD373D-6	TO-237 (90)	80	100		100	25 40	500 100	0.7	1.2*	1A	30	50	420	6	(Notes 5 & 6)	38
BD373D-10	TO-237 (90)	80	100		100	25 63	500 100	0.7	1.2*	1A	30	50	420	6	(Notes 5 & 6)	38
BF240	TO-92 (98)	40	40	4	100	65 6	225 12	0.65	0.74*	1	0.34	1		3.5	(Note 7)	47

T-03-01

Bipolar Pro Electron Series (Continued)

Type No.	Case Style	V _{CE0} [*] (V) Min	V _{CEB0} [*] (V) Min	V _{CE0} [*] (V) Min	V _{EB0} (V) Min	I _{CB0} [*] (mA) Max	I _{CB0} [*] (mA) Max	I _{CB0} [*] (mA) Max	H _{FE} h _{FE} 1 kHz [*] Min Max	I _C (mA) Min Max	V _{CE} (V) Min Max	V _{CE(SAT)} (V) & V _{BE(ON)} [*] (V)		I _C (mA)		C _{ob} (pF) Max	f _T (MHz) Min Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.							
												Max	Min	Max	Min													
BF241	TO-92 (98)	40	40	40	4	100	20	20	35	125	1	10	0.65	0.74*	1	0.34	1			3.5	(Note 7)	47						
BF494	TO-92 (98)	30	30	20	5				65	220	1	10										49						
BF495	TO-92 (98)	30	30	20	5				35	250	1	10										49						
BF536	TO-236 (49)	30	30	30	4	50	20	20	25	1	10											42						
BF840	TO-236 (49)	40	40	40	4	100	20	20	65	220	1	10										47						
BF841	TO-236 (49)	40	40	40	4	100	20	20	35	125	1	10										47						
BF936	TO-92 (97)	30	30	20	4	50	20	20	25	1	10									6	(Note 7)	75						
BFS18	TO-236 (49)	30	30	30	5	100	20	20	35	125	1	10										49						
BFS19	TO-236 (49)	30	30	30	5	100	25	25	65	225	1	10										49						
BSR13	TO-236 (49)	60	30	30	5	30	50	50	35	0.1	10	10	0.4	1.3	150	8	250	20				19						
									50	1	10	10																
									75	10	10	10	1.6	2.6	500													
									100	300	150	10																
BSR14	TO-236 (49)	75	40	40	6	10	60	60	35	0.1	10	10	0.3	0.6	1.2	8	300	20				19						
									50	1	10	10																
									75	10	10	10	1.0	2.0	500													
									100	300	150	10																

Bipolar Pro Electron Series

7

Bipolar Pro Electron Series

Bipolar Pro Electron Series (Continued)																
Type No.	Case Style	V _{CE5} [*] V _{CB0} (V) Min	V _{CE0} (V) Min	V _{EB0} (V) Min	I _{CS0} [*] I _{CS0} @ (nA) Max	H _{FE} h _{FE} @ 1 kHz [*] Min Max	I _C (mA) V _{CE} (V)	V _{CE(SAT)} (V) & V _{BE(ON)} [*] (V) Min Max	V _{BE(SAT)} (V) V _{BE(ON)} [*] (V) Min Max	I _C (mA) Min Max	C _{ob} (pF) Max	f _T (MHz) Min Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
BSR15	TO-236 (49)	60	40	5	20	35	0.1	0.4	1.3	150	8	200	100		(Note 9)	63
BSR16	TO-236 (49)	60	60	5	10	75	0.1	0.4	1.3	150	8	200	100		(Note 9)	63
BSR17	TO-236 (49)	60	40	6	5 μA	20	0.1	0.2	0.65	10		250	250		(Note 5)	23
BSR18	TO-236 (49)	60	40	6	5 μA	35	0.1	0.2	0.65	10		200	300		(Note 5)	66
BSR19	TO-236 (49)	160	140	6	100	60	1	0.15	1.0	10	6	100	300	10	(Note 16)	16
BSR20	TO-236 (49)	130	120	5	100	30	10	0.2	1.0	10	6	100	400	10	(Note 16)	16
BSS38	TO-236 (49)	120	100	5	200	40	4	0.7	1.2	4		60	1000		(Notes 17, 18)	16
BSS63	TO-236 (49)	110	100	6	100	30	10	0.25	0.9	25		50				74
BSS64	TO-236 (49)	120	80	5	100	20	10	0.15	1.2	4		60	1000		(Note 5)	16

T-03-01

Bipolar Pro Electron Series (Continued)

Type No.	Case Style	V _{CE} [*]		V _{BE} [*]		I _{CE} [*]		I _{CB} @ 1 kHz [*]	h _{FE}	V _{CE(SAT)} (V) & Max	V _{BE(SAT)} (V) & Min Max		C _{ob} (pF) Max	f _T (MHz) Min Max	t _{off} (ns) Max	NF (dB) Max	Test Conditions	Process No.
		V _{CE} (V) Min	V _{CE} (V) Max	V _{BE} (V) Min	V _{BE} (V) Max	I _{CB} (mA) Min	I _{CB} (mA) Max				I _{CE} (mA) Min	I _{CE} (mA) Max						
BSS79-B	TO-236 (49)	60	40	5	10	50	40	120	150	10	0.4	150	6	200	20			19
BSS79-C	TO-236 (49)	60	40	5	100	50	100	300	150	10	1.6	500	6	200	20			19
BSS80-B	TO-236 (49)	60	40	5	10	50	40	120	150	10	1.6	500	8	200	20			63
BSS80-C	TO-236 (49)	60	40	5	100	50	100	300	150	10	1.6	500	8	200	20			63
BSV52	TO-236 (49)	20	12	5	100	10	25	1	1	1	0.3	10		400	10	18	(Note 18)	21
BSX39	TO-236 (49)		14		100	12	25	1	1	1	0.25	10				18	(Note 1)	21

TEST CONDITIONS:

- Note 1: I_C = 200 μA, V_{CE} = 5V, f = 1 kHz.
- Note 2: I_C = 100 mA, V_{CC} = 20V, I_B¹ = I_B² = 5 mA.
- Note 3: I_C = 200 μA, V_{CE} = 2V, f = 1 kHz.
- Note 4: I_C = 100 mA, V_{CC} = 10V, I_B¹ = I_B² = 10 mA.
- Note 5: I_C = 10 mA, V_{CC} = 3V, I_B¹ = I_B² = 1 mA.
- Note 6: I_C = 100 μA, V_{CE} = 5V, f = 1 kHz.
- Note 7: I_C = 1 mA, V_{CE} = 10V, f = 200 MHz.
- Note 8: I_C = 1 mA, V_{CE} = 5V, f = 1 kHz.
- Note 9: I_C = 150 mA, V_{CC} = 6V, I_B¹ = I_B² = 15 mA.
- Note 10: I_C = 10 μA, V_{CE} = 5V, f = WB.
- Note 11: I_C/I_B = 20.
- Note 12: I_C = 200 μA, V_{CE} = 5V, f = 30 Hz to 15 kHz.
- Note 13: I_C/I_B = 40.
- Note 14: I_C/I_B = 1000.
- Note 15: I_C/I_B = 33.
- Note 16: I_C = 250 μA, V_{CE} = 5V, f = 10 Hz to 15.7 kHz.
- Note 17: I_C = 15 mA, I_B¹ = I_B² = 1 mA.
- Note 18: I_C/I_B = 3.3.
- Note 19: I_{CE} = 200 μA, V_{CE} = 5V, f = 200 Hz.

T-03-01

Bipolar Pro Electron Series

7